



C Prox Ltd (inc Quantek)

Unit 11 Callywhite Business Park, Callywhite Lane, Dronfield, S18 2XP

+44(0)1246 417113 sales@cproxltd.com www.quantek.co.uk

GO-BUTTON User Manual



Description

Wireless 868MHz wall mount 2 channel push button control, for use with JCM control panels with built in receiver and standalone receivers.

Technical specification

Operating frequency	868.35MHz rolling code
Power supply	3Vdc CR2032
Power consumption	12mA
Radiated power	<25mW
Operating temperature	-20°C to +55°C
Tightness	IP20
Dimensions	84x75x14mm

Installation

Fix the GO-BUTTON to the wall using the plugs & screws provided, within 30 metres of the control panel or receiver. Once fixed place the decorative covers over the screws.

Programming

Open the receiver and press the program button for 1 second until an audible beep is heard, release the button. The receiver is now in programming mode. Within 10 seconds, press one of the buttons on the GO-BUTTON. The receiver will beep to confirm programming. After 10 seconds the receiver will exit programming mode, signified by two consecutive beeps.

Low battery indicator

The indicator lamp flashes for a few seconds after pressing the transmitter.