


12-24v DC


Prog Button

0v Black 

Red +v 

White Norm-Open 

White Common 



Press Prog Button once

LED - On solid

Activate C Prox Transmitter

LED will Flash = Programmed

LED On when activated

RX-MINI-1+

MAX 40 x TX

**To Delete TX
hold Prog Button
for 5 sec**