


C Prox Ltd (inc Quantek)

Unit 11 Callywhite Business Park, Callywhite Lane, Dronfield, S18 2XP +44(0)1246 417113 sales@cproxltd.com www.quantek.co.uk

GT1 Instructions



- 1.When press SELECT, the indicate led light flash, and the press SELECT, it will skip to next led light flash. When press OPEN, the indicate motor will run open, and press STOP or CLOSE key, the motor will stop. When press CLOSE, the indicate motor will run close, and press OPEN or STOP key, the motor will stop.
- 2.When press SELECT ALL, all the LEDs will flash. When press OPEN, all the motors will run open, and press STOP or CLOSE, all the motors will stop. When press CLOSE, all the motors will run close, and press OPEN or STOP, the motors will stop.
- 3. When the motor power on, then press SELECT to select the correspond channel, then press and hold the [OPEN] and [CLOSE] keys over 2 seconds then release, the correspond motor will run open for 1 second then run close for 1 second, this transmitter channel call "MASTER" channel. only this transmitter correspond channel will learn into the control board, other codes in control board will erase, when power on and no operation to control board over 30 seconds, this function will exit.
- 4. When you want to add transmitter code into control board, press SELECT to select the "MASTER" channel, then press and hold the [OPEN] and [CLOSE] keys over 2 seconds then release, the correspond motor will run open for 1 second then run close for 1 second, the learn function will open, then press SELECT to select the correspond channel you want to add, press and hold [OPEN] and [CLOSE] keys over 2 seconds then release, the correspond motor will run open for 1 second then run close for 1 second, learn function finish. If learn function open and no operation to control board over 30 seconds, this function will exit.
- 5. When you want to change motor run direction, press SELECT to select "MASTER" channel, press and hold [OPEN] and [CLOSE] buttons for 2 seconds then release, the correspond motor will run open for 1 second then run close for 1 second, the learn function will open, then press and hold the "MASTER" channel [CHANGE] button by a small needle over 2 seconds then release, the correspond motor will run open for 1 second then run close for 1 second, change motor run direction function finish. If learn function open and no operation to control board over 30 seconds, this function will exit.